

Link to the product: <https://sforne.com/durex-toy-vibe-tease-vibrator-p-3084.html>



DUREX - TOY VIBE & TEASE VIBRATOR

Price	43.84 £
Number	70135926
Producer code	FETISHID-238077
EAN	5011417588895

Product description

Surf the waves of pleasure with **Vibe & Tease**, Durex's multi-speed Bunny Vibrator. Mix and match: Use the vibrator alone or attach the stimulator tip to experience a different targeted stimulation!

With seven vibration modes, The Bunny Vibrator **Vibe & Tease** by Durex is the ideal toy for those who want to try something different or simply explore. Find out what it's what raises your temperature. This toy offers unlimited possibilities for pleasure, both alone and as a couple. Whether in the shower or in bed, the **Vibe & Tease** Vibrator is Designed to make you enjoy and is waterproof. Enhance your gaming moments by combining it with a Durex water-based lubricant for a better experience

CHARACTERISTICS:

- 60 minutes of non-stop fun, minimum
- 7 vibration settings
- Stimulator tip for localized stimulation
- Water resistant
- Discreet travel bag
- Easy to clean
- USB recharge battery
- Recyclable packaging!

How to use:

1. Hold down the X button for 3 seconds, the white LED light will flash. to start the vibrations and explore the 7 intensities by pressing the X button.
2. Place the stimulator tip on the rounded end of the vibrator, applying light pressure until the tip is firmly seated on the top of the vibrator, making sure it locks in place. Make sure you don't place it on the flat end of the vibrator. Play with the different levels of vibration intensity to experience a different specific stimulation with the stimulator tip.
3. To turn off the device, press and hold the X button for 3 seconds, the white LED light will flash.

You can use the vibrator with any Durex water-based lubricant. Make sure not to insert the vibrator into the vagina when the stimulator tip is open. placed

Use the vibrator alone or attach the stimulator tip to experience a different, targeted stimulation. Discover the different speeds and intensities and enjoy the one you like the most. You can explore anywhere, whether in bed or in the shower, since it is 100% waterproof.

Always clean the toy before and after each use. It is recommended to store it in the included bag. We recommend that you

read the leaflet with instructions on how to use it and how to store it. This product is not for anal use.

Toy Guide

Adult Toy Guide

Start with a small vibrator or bullet. Add lubricant. Clean after each use.

Explore categories to find what excites you.