

Link to the product: <https://sforne.com/ibiza-clip-up-down-vibrator-clitoris-sucker-p-13853.html>



IBIZA - CLIP UP & DOWN +VIBRATOR + CLITORIS SUCKER

Price	87.63 £
Number	73751600
Producer code	FETISHID-234722
EAN	8435566040269

Product description

Ibiza? Up&Down Vibrator pampers the clitoris with sensual pressure waves and the G-spot with powerful vibrations. Thanks to the up&down system, the silicone vibrator adapts to your anatomy and delights you with optimal stimulation.

1 - IBIZA UP&DOWN? TECHNOLOGY

- Without making direct contact, the sonic waves of IBIZA? Up&Down offer rapid but gentle stimulation to the clitoris so that you achieve immense pleasure, adding a strong sensation of pleasure with Up&Down technology.

2 - DOUBLE EXCITATION

- Simultaneously caress the clitoris (both the part that is visible and the part that cannot be seen) and the G-spot.

3 - ERGONOMIC INTERNAL STIMULATOR

- two2 motors with independent control
- 10 Suction Modes
- 10 Vibration Modes.
- Waterproof (IPX3)
- Body-friendly silicone
- Vibration from soft to intense.
- Waterproof (IPX6)
- Lithium-ion battery Easy to clean

****Note;** This product is prohibited from being sold on any E-commerce channel. The sale is authorized for physical points.

Ibiza? Up&Down Vibrator: double pleasure with pressure waves and G-spot massage

Ibiza? Up&Down Vibrator adapts to any body shape and provides you with unique pleasure. While the elegantly curved handle massages your G-spot with penetrating vibrations and the Up&Down system, pressure waves coming from the outside guarantee intense clitoral stimulation. Thanks to the Ibiza Flex silicone technology and a chain joint located inside, you can easily adjust the Ibiza? Up&Down Vibrator to ensure that the clitoral sucker with pressure waves reaches your hottest spot perfectly and transmits its vibrations with special intensity. Plus, the handle is wide enough so you don't lose your grip.

The two powerful motors can also be controlled independently, while 10 different vibration programs and 11 intensities offer countless combination options and varied pleasure.

CLEANING

Thoroughly clean the toy before and after each use with warm water and mild soap.

STORAGE

Store your Ibiza? Up&Down Vibrator toy in a dust-free place and keep it away from toys made of other materials. Avoid leaving it in direct sunlight and NEVER expose it to extreme heat.

USE TIPS

Ibiza? Up&Down Vibrator recommends the use of water-based lubricants such as Waterfeel?, Aqua?, Bioaqua?, Aquatravel? or Coquette? for easy and smooth insertion of all silicone products. Do not use silicone lubricants, oils or creams with any silicone product as they may degrade the product material and limit its performance and life.

3 YEARS WARRANTY

This warranty applies to all Ibiza? Up&Down Vibrator products purchased, starting from the date of original purchase of said product. This warranty does not cover damage caused by misuse or use other than that intended and described in the product's instruction manual, normal wear and tear, alteration, unreasonable use, service by unauthorized service agencies, or loss or damage to batteries or batteries. removable.

Toy Guide

Adult Toy Guide

Start with a small vibrator or bullet. Add lubricant. Clean after each use.

Explore categories to find what excites you.