

Link to the product: <https://sforne.com/lelo-clitoris-stimulator-sona-fuchsia-color-p-15674.html>



LELO - CLITORIS STIMULATOR SONA FUCHSIA COLOR

Price	98.95 £
Number	86304051
Producer code	FETISHID-213747
EAN	7350075026157

Product description

The SONA™ sonic massager represents an absolutely new concept of pleasure: it stimulates the entire clitoris, its external and internal part, with waves of consistent pulses, to achieve a different type of orgasm through massage with sonic waves.

An extended climax after a sensual progressive arousal, an orgasm that comes from somewhere inside you.

Characteristics

- Completely submersible.
- Easy to clean
- The soft, submersible material makes it incredibly easy to clean.
- USB rechargeable. With its included USB charging cable, you can take your SONA wherever you go.
- 8 modes for pleasure. A selection of stimulation modes designed so that you can find the sensation that you most want.

How to use:

- To unlock it, press the +/- buttons for 3 seconds, until the light turns on.
- Press the + button to turn it on and to increase the intensity of the vibrations. Press the () button to try its 8 stimulation modes.
- Press the - button to reduce the intensity of the vibrations, and press it to turn it off.

Technical specifications:

- Material: ABS and silicone
- Finish: matte and glossy
- Size: 99 x 88 x 56mm
- Weight: 116g
- Battery: Li-Ion 530mA 3.7V
- Charging time: 2 ore at 5.0 V 100 mA
- Duration: 1h
- Stimulation modes: 8
- Frequency: 120Hz
- Max. noise level: <50dB
- Interface: 3 buttons
- Cherry color