

Link to the product: <https://sforme.com/lelo-lily-3-personal-massager-aqua-green-p-5430.html>



## LELO - LILY 3 PERSONAL MASSAGER - AQUA GREEN

Price	<b>124.01 £</b>
Number	<b>70138272</b>
Producer code	<b>FETISHID-233262</b>
EAN	<b>7350075029127</b>

### Product description

Embark on a passionate journey with the LILY™ 3 personal massager and indulge in subtle orgasmic stimulation with its ten powerful pleasure modes. Although small in size, it has been designed to unleash sensations and make you enjoy an unforgettable experience, whether you use it with your partner or alone.

**READY TO TRAVEL** : Its compact and discreet design allows you to carry LILY™ 3 with you wherever you go.

**10 POWERFUL VIBRATION MODES** : LILY™ 3 offers ten vibration patterns with different intensities; from soft touches to very exciting pulses.

**RECHARGEABLE BY USB AND 100% WATERPROOF ACCORDING TO IPX7 STANDARD** : Enjoy unlimited climaxes anytime, anywhere, including the bath or shower.

#### CHARACTERISTICS:

**Materials:** biocompatible silicone and ABS plastic

**Finish** : smooth

**Size** : 39 x 34 x 74mm

**Weight** : 45g

**Battery** : Li-ion 3.7 V with 300 mAh

**Charge** : up to 2 hours

**Rated potential** : Input: 5 V 1.5 W // Output: 3.7 V 0.7 W

**Use time** : up to 2 hours

**Standby** : up to 90 days

**Frequency:** 93Hz

**Max level Noise:** <60 dB

---

**Interface** : 2 buttons

**INSTRUCTIONS FOR USE:**

- Before first use, charge your LILY™ 3 for 2 hours.
- The device interface may be blocked. Press and hold both buttons for 5 seconds.
- Press and hold the right button to turn it on.
- Press twice quickly to change modes.
- Press the left or right button for a semi-long moment to increase or decrease the intensity.
- Press and hold the left button to turn it off.

## Toy Guide

### **Adult Toy Guide**

Start with a small vibrator or bullet. Add lubricant. Clean after each use.

Explore categories to find what excites you.