

Link to the product: <https://sforne.com/lelo-ora-3-oral-sex-stimulator-midnight-blue-p-2207.html>



## LELO - ORA 3 ORAL SEX STIMULATOR MIDNIGHT BLUE

Price	<b>224.24 £</b>
Number	<b>70135049</b>
Producer code	<b>FETISHID-222029</b>
EAN	<b>7350075027833</b>

### Product description

LELO's sophisticated oral sex simulator made an impression in 2014, winning international awards at the Cannes Lions and A-Design Awards, both for best Product Design. ORA™ 3 is the perfected version that now has a larger, faster and firmer tongue and more precisely replicates the desired stimulation of an almost perfect, almost infinite cunnilingus.

#### TONGUE WITH BIGGER, FIRMER, MORE FLEXIBLE ROTATION

- So that nothing gets in the way of the most intense climax With 12 vibration patterns to simulate the most pleasurable oral sex

#### EXTRA-SOFT SILICONE

- With extra-soft and biocompatible premium silicone

#### PREMOTION™ TECHNOLOGY

- With a firmer and more precise movement, for 25% faster oral sex simulation

Elevate your intimate moments to new sensual heights with ORA™ 3, the award-winning oral sex simulator, now perfected. And delight in the honeys of an illustrated and almost eternal cunnilingus, thanks to its power and improved tongue.

- 12 powerful vibration modes
- A faster tongue for total pleasure
- Extra-soft premium silicone
- 100% submersible and USB rechargeable
- 1 year warranty and 10 years quality guarantee

#### What is PreMotion™ technology?

ORA™ 3 comes with PreMotion™ technology to offer you a more realistic oral sex simulation, thanks to a firmer, more precise movement and 25% more speed.

#### SPECIFICATIONS

- Material: Silicone, PC, ABS.
- Size: 83.5 x 88 x 43.5mm
- Weight: 130g
- Battery: Li-Ion 420mA 3.7V
- Charge: 2 hours at 5.0V 400mA
- In use: up to 1 hour
- Standby: 90 days

- 
- Frequency: 100Hz
  - Interface: 3 buttons

## Clit Guide

### **Clitoral Toy Guide**

Start with lower speeds, increase gradually. Use lubricant for comfort. Many women prefer clitoral toys over internal stimulation.

Clean after each use with soap and water or toy cleaner.