

Link to the product: <https://sforne.com/lelo-sila-pink-clitoris-wave-stimulator-p-15672.html>



## LELO - SILA PINK CLITORIS WAVE STIMULATOR

Price	<b>139.66 €</b>
Number	<b>86304059</b>
Producer code	<b>FETISHID-225670</b>
EAN	<b>7350075028328</b>

### Product description

Discover new ways to reach climax with SILA™ and experience the wonders of clitoral stimulation through its delicate sonic waves.

Immerse yourself in a spiral of eternal orgasms with this beautiful massager, whose mouth orbits around your pleasure point and turns a sensual experience into a comfortable series of infinite orgasms

#### CHARACTERISTICS

##### VERY DELICATE SONIC WAVES

- The SILA's sonic waves gently stimulate your clitoris so that you can enjoy a highly intense climax and immerse yourself in a spiral of orgasms.

##### WIDER MOUTH

- Without coming into direct contact with your body, the wide mouth of your SILA orbits around the center of your pleasure point, in a comfortable and satisfying way.

##### EXTRA SOFT SILICONE

- It is made of ultra-soft, body-safe silicone so you have a unique sensual experience and total peace of mind. 100%

##### SUBMERSIBLE AND USB RECHARGEABLE

- With the included USB charger, you can take your SILA™ wherever you want since in addition to being soft and submersible, it is very easy to clean.

#### TECHNICAL SPECIFICATIONS

- Use time: Up to 2 hours
- Standby: 90 days
- Frequency: 60Hz
- Interface: 3 buttons
- Material: body safe silicone, ABS
- Size: 80 x 75 x 35mm
- Weight: 105g
- Battery: Li-Ion 520 mA 3.7 V
- Load: 2 h at 5.0V 500 mA

#### HOW TO USE IT:

- 
- Make sure SILA™ is unlocked by pressing and holding the + and - buttons for 3 seconds until the light turns on.
  - Press the + button to turn it on and press it again to increase the vibration intensity.
  - Press the ( ) button to switch to any of the 8 vibration patterns.
  - Press the - button to reduce the vibration power.
  - Press the button ( ) to turn it off.