Data current as of: 03-11-2026 11:54

Link to the product: https://sforne.com/lelo-switch-vibrator-wanda-double-stimulation-aqua-p-15487.html



LELO - SWITCH VIBRATOR WANDA DOUBLE STIMULATION AQUA

Price	**249.28 £**
Number	**84263912**
Producer code	**FETISHID-244538**

Product description

LELO SWITCH™ is a double-ended vibrator designed for versatile pleasure. Crafted with a seamless, ergonomic silhouette, it features ultra-smooth sensory ridges for enhanced nerve stimulation and tactile feedback. It connects to the **LELO™** app, allowing remote control and customizable settings. Compact, stylish, and functional, it's ideal for those looking for more from their pleasure products, offering the best of both worlds in one sleek design.

- DOUBLE STIMULATION: A double-ended vibrator with two built-in motors allows for seamless switching between external massage and internal stimulation, for double the pleasure every time.

- SENSORY RIBS: Ultra-smooth, textured ridges increase sensitivity by stimulating more nerve endings and increasing blood flow for deeper, fuller sensations.

- SMART APP CONNECTIVITY: Connect to the LELO™ app for remote control, custom vibration patterns, and partner play—pleasure at your pace or theirs.

- ULTRA-SOFT BODY-SAFE SILICONE: Made with premium silicone that's soft and warm to the touch.

FEATURES:

- Materials: Body-safe silicone, ABS plastic
- Finish: Smooth
- Size: 217 x 64 x 43 mm
- Insertable length: 83 mm
- Weight: 167 g ±10%
- Battery: Lithium 3.7V, 1000 mAh
- Charging time: Less than 2 hours
- Power: Input 5V 1000 mA (5 W) / Output 3.7V 800 mA (2.96 W)
- Use time: Up to 2 hours (automatically shuts off every 20 minutes)
- Standby mode: Up to 90 days
- Top motor frequency: 100 Hz
- Handle motor frequency: 93 Hz
- Maximum noise level: <63 dB
- Interface: 3 buttons and 2 LED lights

Brand characteristics

Brand characteristics: selected LELO products available at Sforne with discreet delivery and clear product information.

Toy Guide

Adult Toy Guide

Start with a small vibrator or bullet. Add lubricant. Clean after each use.

Explore categories to find what excites you.