

Link to the product: <https://sforne.com/moressa-edgar-premium-silicone-remote-control-p-4675.html>



MORESSA - EDGAR PREMIUM SILICONE REMOTE CONTROL

Price	41.28 €
Number	70137527
Producer code	FETISHID-213230
EAN	8425402155776

Product description

Choose your lover and share the vibes!

Edgar provides sensations directed especially to the clitoris and is also valid for vaginal introduction. Soft 100% medical silicone design provides incomparable pleasure and extreme comfort. Edgar works via remote control and both pleasure objects vibrate at the same time, synchronously or separately. You can activate Edgar anywhere and comfortably enjoy the powerful and silent vibration. Designed to play alone or with a partner in a new dimension. From the tip to its base it adapts naturally to your body temperature.

- Super soft 100% medical silicone.
- Waterproof
- Edgar Stimulator Measurements; 93x45mm
- Edgar Egg Measurements; 75x33mm
- Weight; 112 Grams
- 12 vibration modes
- Body safe material
- Phthalate free
- unisex
- Synchronized remote control (Both objects vibrate at the same time or separately)
- USB rechargeable (Cable included)
- Ergonomic
- Backlit control with LED lights

Operation/Use

Stimulating;

To turn on Edgar Stimulator press the button power button for 2 seconds and it will activate the red light. Press the button which will activate the vibration, and then modify the vibration modes by pressing the same key. Press the button which will activate the remote control for the Edgar Egg (Both will vibrate simultaneously up to 5 meters away). Once Edgar has finished press the button for two seconds and it will turn off.

Egg Edgar;

To turn on Edgar Egg press the button for two seconds and it will activate the vibration, then press the button which will activate the different vibration modes. You can also use it remote control through the Edgar Stimulator.

Carry

The vibrator is rechargeable and allows for comfortable handling, without annoying cables. Before using it for the first time, you must fully charge it. Use the included USB charging cable to do this.

Insert the USB cable plug into the charging connection hole. Plug into the power with a connector or to the computer via USB.

Warning : the first charging process can take up to eight hours.

Troubleshooting

In case of errors or handling difficulties related to the operation of Brad, press the power button for 5 seconds. If the product still does not work, contact: info@amoressa-toys.com

Elimination

Disposal of electronic devices must be carried out in accordance with the regulations for hazardous waste in force in the European Union and other European countries or according to local regulations. Respect garbage disposal regulations

Specific to your country and if in doubt, ask your dealer about disposal options.

Content

Opening a box of MORESSA products is exclusivity. Satisfaction is our goal, which is why we have taken care of every detail.

- EDGAR
- Charger
- User manual

Moressa is the benchmark brand for its design, quality and technology. We have developed an innovative product and taken care of each manufacturing process to achieve the best result. Moressa is a symbol of energy, strength and guarantee. Buying a Sextoy Moressa is to feel reflected in today's news. Each Moressa Toy will transport you to different sensations. An unmatched result thanks to the comfortable Premium silicone and ergonomic designs.