

Link to the product: <https://sforne.com/moressa-gino-premium-silicone-rechargeable-p-4687.html>



MORESSA - GINO PREMIUM SILICONE RECHARGEABLE

| | |
|---------------|------------------------|
| Price | 75.11 £ |
| Number | 70137529 |
| Producer code | FETISHID-213232 |
| EAN | 8425402155790 |

Product description

Perfect: Attractive rechargeable massager vibrator

Powerful: Optimized distribution of vibrations throughout the entire silicone body

- Gino has a 100% medical silicone body with fair robustness, especially flexible at its ends that pleasantly presses the erogenous zones and facilitates its use in countless positions – for HER and for HIM.
- Energetic: 7 quiet powerful low frequency vibration programs.
- Unstoppable: Tickling System, Massages the G-spot better than two fingers at a time

Stimulating reliefs on the silicone tip for greater pleasure during introduction.

From the tip to its base it adapts naturally to your body temperature.

The world of vibrating bunnies is reinvented with Gino.

- 100% soft medical silicone
- 7 Vibration functions
- 3 Tickling Movement Modes
- Waterproof
- Body safe material
- Phthalate free
- Total Measurement; 190 x 35mm
- Weight; 132 grams
- Flexible
- USB rechargeable (Cable included)
- Ergonomic
- clitoral stimulation
- Backlit control with LED lights

Operation/Use

To turn on the vibrator, press the button power button for about 2 seconds and a red light will come on. Successively press

the same button to cycle through the 7 vibration modes. Press the button To activate the Tickling system, a Blue LED will light up, then press the same button to modify the 3 oscillation modes. Once Gino has finished press the button for two seconds and it will turn off the vibration, to turn off the Tickling system press the button for two seconds.

Carry

The vibrator is rechargeable and allows for comfortable handling, without annoying cables. Before using it for the first time, you must fully charge it. Use the included USB charging cable to do this.

Insert the USB cable plug into the charging connection hole. Plug into the power with a connector or to the computer via USB.

Warning : the first charging process can take up to eight hours.

Troubleshooting

In case of errors or handling difficulties related to the operation of Brad, press the power button for 5 seconds. If the product still does not work, contact: info@amoressa-toys.com

Elimination

Disposal of electronic devices must be carried out in accordance with the regulations for hazardous waste in force in the European Union and other European countries or according to local regulations. Respect garbage disposal regulations

Specific to your country and if in doubt, ask your dealer about disposal options.

Content

Opening a box of MORESSA products is exclusivity. Satisfaction is our goal, which is why we have taken care of every detail.

- GINO
- Charger
- User manual

Moressa is the benchmark brand for its design, quality and technology. We have developed an innovative product and taken care of each manufacturing process to achieve the best result. Moressa is a symbol of energy, strength and guarantee. Buying a Sextoy Moressa is to feel reflected in today's news. Each Moressa Toy will transport you to different sensations. An unmatched result thanks to the comfortable Premium silicone and ergonomic designs.