

Link to the product: <https://sforne.com/moressa-warren-premium-rechargeable-silicone-p-3007.html>



MORESSA - WARREN PREMIUM RECHARGEABLE SILICONE

Price	87.63 £
Number	70135849
Producer code	FETISHID-213252
EAN	8425402155875

Product description

AWESOME strong and impactful: WARREN's strong structure intensely pampers the G-spot, the clitoris and each and every one of the most hidden erogenous zones.

Everything you want in one toy!!

- Vibration, clitoral stimulation, intense penetration with Rolling system.
- Ideal for use alone or with others, WARREN is elegant with a silky soft touch.
- Rolling; Oscillating impulse system using internal balls that intensely stimulate the vaginal wall.
- Open the doors to a new universe of pleasure with WARREN, a toy that drives, shakes, vibrates and offers you what you always need.
- POWERFUL, rampant bunny clitoral vibrator, scream with pleasure when you feel it!
- Go through the 7 vibration modes + 4 Rolling functions
- Wrapped in hypoallergenic and velvety silicone, one of the best materials, the entire vibrator from its tip to its base adapts quickly and naturally to your body temperature.

Warren is up to everything you need! Just perfect!

- 100% medical silicone
- Body safe material
- Waterproof
- 7 vibration modes
- 4 modes Rolling function
- Phthalate free
- Total Measurement; 25.5 x 4cm
- Weight; 160 grams
- USB rechargeable (cable included)
- Ergonomic
- Backlit control with LED lights
- clitoral stimulation

Operation/Use

.Press the key to activate Warren, then press the key which will activate the pulses, modify the pulse modes by pressing the same key . Continue pressing the key and will activate the vibration of the Rabbit stimulator, then press the same key and will modify the vibration modes. Once Warren has finished press the key off for 3 seconds.

Carry

The vibrator is rechargeable and allows for comfortable handling, without annoying cables. Before using it for the first time, you must fully charge it. Use the included USB charging cable to do this.

Insert the USB cable plug into the charging connection hole. Plug into the power with a connector or to the computer via USB.

Elimination

Disposal of electronic devices must be carried out in accordance with the regulations for hazardous waste in force in the European Union and other European countries or according to local regulations. Please observe your country's specific waste disposal regulations and, if in doubt, ask your dealer about disposal options.

Content

Opening a box of MORESSA products is exclusivity. Satisfaction is our goal, which is why we have taken care of every detail.

- warren
- Charger
- User manual

Moressa is the benchmark brand for its design, quality and technology. We have developed an innovative product and taken care of each manufacturing process to achieve the best result. Moressa is a symbol of energy, strength and guarantee. Buying a Sextoy Moressa is to feel reflected in today's news. Each Moressa Toy will transport you to different sensations. An unmatched result thanks to the comfortable Premium silicone and ergonomic designs.