

## NALONE - TOUCH 2 SMART VIBRATOR



Price	<b>80.16 €</b>
Number	<b>70137432</b>
Producer code	<b>FETISHID-207044</b>
EAN	<b>6926511600758</b>

### Product description

Discover a new concept, did you think you had seen it all? Nalone hides more than what you see, at first glance a normal vibrator, inside cutting-edge technology at the service of pleasure.

Touch features a silicone exterior and an elegant, ergonomic design that makes it one of our most seductive and attractive products. If that were not enough, the digital control allows you to adjust the intensity of the vibrations

Incorporates Touch technology; Vibrates at the level you press.

2 Motors for intense stimulation of the Clitoris and G-Spot simultaneously.

#### Specifications;

- Material: Silicone and ABS
- Vibration Modes: 7+Touch Functionality
- Dimensions: 218mm(L) x 46mm(W) x 64mm(H)
- Charge: Rechargeable lithium polymer
- Average usage time on one charge: 2 hours
- 100% waterproof
- Average charging time: 3 hours

①Vibrating tip②Vibrating tip③Logo④Manual mode button⑤ON/OFF button⑥Digital mode button⑦ Inductive metal sheet

#### Manual stimulation modes

- 1. Slow vibration
- 2. Medium vibration
- 3. Fast vibration
- 4. Gentle pulse vibration
- 5. Medium pulse vibration
- 6. Strong pulse vibration
- 7. Mixed vibration: short and long

#### How is it used?

- 1. To charge your vibrator, connect the charger's USB cable to a USB adapter (5V/1A adapter is recommended). Connect the other part of the USB cable to the base of the vibrator (at the bottom of the vibrator). While charging, a blue light on the control panel will flash to indicate charging is in progress. Once charged, the light will stop flashing to

---

indicate that it is ready for use. Please note that the first time you use it, or if you haven't used it in a long time, the light may not turn on for a few minutes.

- 2.If you want to massage yourself internally, use a condom.
- 3.To turn on your vibrator, please press and hold the button for 3 seconds.
- 4.If you quickly press the button , the vibrator will be put into manual mode and into the first vibration mode. Every time you press the button will change the vibration mode, going through the 10 available modes. In both standby or manual mode, by holding down the buttonThe vibrator will change to automatic mode. Vibrator mode starts when you touch the sensitive metal around the control panel
- 5.To turn off the vibrator, hold the button pressed for 3 seconds.
- 6.Every time you use it, be sure to clean your vibrator with warm water and antibacterial soap. After cleaning, dry it with a clean, soft towel and store it in the included bag in a cool, dry place.

## **Warnings**

- ◆Be sure to charge the vibrator fully before use.
- ◆Clean/disinfect your vibrator with warm water and antibacterial soap.
- ◆Use only water-soluble lubricants. Never use massage oils, hand creams or other types of lubricant.

## **Cleaning and Care**

- ◆ After use, it is advisable to clean the vibrator to prevent bacterial growth.
- ◆ Warm water and antibacterial soap can be used to clean the vibrator.
- ◆ Dry the vibrator with a clean, soft towel and store it in the included bag. Do not expose your vibrator to direct sunlight.
- ◆ Store your vibrator in the included bag in a clean, dry place

Opening a box of NALONE products is a guarantee of quality. Each product is wrapped in an elegant and unique rigid white box, in which you will find inside

- Touch 2 Vibrator
- USB Cable
- satin cover
- 1 year warranty
- User manual
- Instructions for use