Link to the product: https://sforne.com/we-vibe-sync-o-flexible-vibrator-remote-control-dark-green-p-14243.html



WE-VIBE - SYNC O FLEXIBLE VIBRATOR REMOTE CONTROL DARK GREEN

Price	43.23 €
Number	77643244
Producer code	FETISHID-238123
EAN	4251460622912

Product description

We-Vibe Sync o - Vibrator for couples. **Sync O** is a new type of vibrator in C-shaped for pleasure seekers looking for the perfect fit. The outer arm rests against the clitoris while the flexible O-shaped inner arm fits comfortably into the vagina ensuring the vibrations stay right where you want them. We-Vibes unique C-shaped innovation provides effortless, handsfree stimulation that delivers safe, delicious vibrations that both partners can enjoy.

CHARACTERISTICS:

- IPX7 waterproof: Enjoy a bath or shower with IPX7 waterproofing
- **USB rechargeable**: Easy, fast and reliable recharging with USB cable
- Adjustable fit: Worn during sex, *toy* adapts to your unique body
- We-Vibe App: Control your toys, even from a distance, with a tap on your smartphone screen
- Secure Fit: The unique internal O-shaped arm keeps the toy perfectly in place to share vibrations, wherever you want them.
- Flexible and comfortable: The lightweight silicone inner loop keeps Sync O stable without being intrusive or distracting for a more intimate and comfortable connection. effortless.
- **Effortless Use**: The internal **Sync O** arm keeps the toy and its rumbling vibrations securely in the right place, regardless of whether it is used with your hands free in solo games or together with a partner during sex.

SPECIFICATIONS:

- Model: Silicone rechargeable C-shaped couples vibrator
- Colors: Dark green and violet
- Battery: USB rechargeable lithium-ion polymer battery
- Vibration: 9 modes
- Running time: 150 minutes
 Charging time: 90 minutes
- Materials: Body-safe silicone. Free of phthalates and BPA and made without latex.
- **Dimensions**: 80 x 44 x 44.5 mm length x width x height

How to play?

- 1. Apply some lubricant to the inner arm of the toy and squeeze the flexible inner arm to allow for easy insertion. The soft O-shaped loop unfolds once inside and is lightweight for easy adjustment. comfortable and safe. With the toy inserted, turn it on by pressing the control button on its base.
- 2. Cycle through different modes of vibration patterns and intensity levels using the control button on the toy or the We-Vibe app. You can also use the remote control to control the toy.
- 3. /li>

4. Enjoy shared vibrations using the toy during penetration.	