

Link to the product: <https://sforne.com/we-vibe-sync-o-flexible-vibrator-remote-control-dark-green-p-14253.html>



## WE-VIBE - SYNC O FLEXIBLE VIBRATOR REMOTE CONTROL DARK GREEN

Price	<b>211.70 £</b>
Number	<b>77643244</b>
Producer code	<b>FETISHID-238123</b>
EAN	<b>4251460622912</b>

### Product description

**We-Vibe Sync o** - Vibrator for couples. **Sync O** is a new type of vibrator in C-shaped for pleasure seekers looking for the perfect fit. The outer arm rests against the clitoris while the flexible O-shaped inner arm fits comfortably into the vagina ensuring the vibrations stay right where you want them. . We-Vibes unique C-shaped innovation provides effortless, hands-free stimulation that delivers safe, delicious vibrations that both partners can enjoy.

#### CHARACTERISTICS:

- **IPX7 waterproof:** Enjoy a bath or shower with IPX7 waterproofing
- **USB rechargeable:** Easy, fast and reliable recharging with USB cable
- **Adjustable fit:** Worn during sex, \*toy\* adapts to your unique body
- **We-Vibe App:** Control your toys, even from a distance, with a tap on your smartphone screen
- **Secure Fit:** The unique internal O-shaped arm keeps the toy perfectly in place to share vibrations, wherever you want them.
- **Flexible and comfortable:** The lightweight silicone inner loop keeps **Sync O** stable without being intrusive or distracting for a more intimate and comfortable connection. effortless.
- **Effortless Use:** The internal **Sync O** arm keeps the toy and its rumbling vibrations securely in the right place, regardless of whether it is used with your hands free in solo games or together with a partner during sex.

#### SPECIFICATIONS:

- **Model:** Silicone rechargeable C-shaped couples vibrator
- **Colors:** Dark green and violet
- **Battery:** USB rechargeable lithium-ion polymer battery
- **Vibration:** 9 modes
- **Running time:** 150 minutes
- **Charging time:** 90 minutes
- **Materials:** Body-safe silicone. Free of phthalates and BPA and made without latex.
- **Dimensions:** 80 x 44 x 44.5 mm length x width x height

#### How to play?

1. Apply some lubricant to the inner arm of the toy and squeeze the flexible inner arm to allow for easy insertion. The soft O-shaped loop unfolds once inside and is lightweight for easy adjustment. comfortable and safe. With the toy inserted, turn it on by pressing the control button on its base.
2. Cycle through different modes of vibration patterns and intensity levels using the control button on the toy or the We-Vibe app. You can also use the remote control to control the toy.
3. /li>

---

4. Enjoy shared vibrations using the toy during penetration.

## Toy Guide

### **Adult Toy Guide**

Start with a small vibrator or bullet. Add lubricant. Clean after each use.

Explore categories to find what excites you.