

Link to the product: <https://sforne.com/womanvibe-mandy-k-point-silicone-rechargeable-vibrator-p-2724.html>



WOMANVIBE - MANDY "K" POINT SILICONE RECHARGEABLE VIBRATOR

Price	50.06 £
Number	70135566
Producer code	FETISHID-213869
EAN	8425402156421

Product description

Womanvibe launches Mandy, a dual motor vibrator that offers intense stimulation, in an elegant and pleasant way. Mandy is perfect for a masturbation that elevates you to maximum pleasure. Mandy incorporates silicone free of phalates 100% safe for your skin and details in Abs, completely flexible it adapts to your body.

- Measurements; 19.9 x 3.5 cm
- Silent and discreet
- Powerful
- 10 vibration modes.
- Special point "K"
- Flexible
- Easy to use one-button keys.
- Charge indicator
- Materials that do not irritate the skin
- Approximately one hour of uninterrupted pleasure at the highest intensity
- 2 years warranty.

Mandy is vibe smart! 10 vibration modes from soft to strong transmitting powerful low-frequency vibrations.

- 100% rechargeable battery.

Mandy is completely submersible perfect for use in Spa or Shower.

A perfect playful vibrator that promises you immediate satisfaction.

Instructions for use;

- Press the button for 3 seconds and it will activate vibration in mode 1, then press again to cycle through the 10 appetizing vibration modes.

Light Indicator;

- When the vibrator is running you will see a white led light on the vibrator.
- When the vibrator is off, no led lights will stay on behind the buttons.
- When inserting the charger cable, the vibrator will have a flashing white led light.
- When the vibrator is charged, the light stays fixed.

Load

The vibrator is rechargeable and allows comfortable handling, without annoying cables. Before using it for the first time, you must fully charge it. Use the included USB charging cable for this. Insert the plug of the USB cable into the charging

connection hole. Plug into the power with a connector or to the computer via USB. While the massager is charging a light will be in intermittent mode, once the charge is finished the led light will remain fixed.

Warning : the first charging process can take up to five hours.

Problem solving

In case of errors or handling difficulties related to the operation of Mandy, press the power button for 5 seconds. If the product still does not work, please contact; service@womanvibe-toy.es

Elimination

Disposal of electronic devices must be carried out in accordance with the regulations for hazardous waste in force in the European Union and other European countries or according to local regulations. Please follow your country-specific waste disposal regulations and, if in doubt, ask your dealer about disposal options.

Content

Opening a box of Womanvibe products is exclusive. All products include Deluxe presentation box in gold background.

Inside you will find

- Mandy vibrator
- USB charger

Toy Guide

Adult Toy Guide

Start with a small vibrator or bullet. Add lubricant. Clean after each use.

Explore categories to find what excites you.