

Link to the product: <https://sforne.com/lelo-loki-wave-2-prostatic-massager-black-p-5399.html>



## LELO - LOKI WAVE 2 PROSTATIC MASSAGER - BLACK

Price	<b>274.34 £</b>
Number	<b>70138241</b>
Producer code	<b>FETISHID-232970</b>
EAN	<b>7350075028960</b>

### Product description

Here is the new generation of our legendary vibrating prostate stimulator. LOKI Wave™ 2 moves back and forth with a finger-like internal massaging motion for sweeping prostate stimulation. Experience unprecedented orgasmic satisfaction thanks to the 12 pleasure modes powered by 2 motors and its flexible and ergonomic internal massager arm that we have completely redesigned. Feel the intensity inside you and enjoy the pleasure with the stylish LOKI Wave™ 2.

**12 POWERFUL VIBRATION MODES:** LOKI Wave™ 2 offers 12 vibration patterns with different intensities; from soft touches to very exciting pulses.

**EXTRA SOFT SILICONE :** High-quality silicone that is ultra-soft and warm to the touch so you can enjoy a deeply gratifying and hygienic pleasure at the same time.

**USB RECHARGEABLE AND 100% WATERPROOF TO IPX7 STANDARD :** Enjoy unlimited climaxes anytime, anywhere, including in the bath or shower.

**GREATER POWER FOR MORE INTENSE PLEASURE :** With 2 motors that focus precisely on the prostate and perineum to achieve much more explosive climaxes.

#### CHARACTERISTICS:

**Materials:** biocompatible silicone and ABS plastic

**Finish :** smooth

**Size :** 91 x 42 x 196mm

**Insertable length :** 100 mm

**Weight :** 196g

**Battery :** lithium 850 mAh 3.7 V

**Charge :** up to 2 hours at 5.0 V 750 mA

**Use time :** up to 2 hours

---

**Standby** : up to 90 days

**Frequency**: 122Hz

**Max level Noise**: <60 dB

**Interface** : 5 buttons

**INSTRUCTIONS FOR USE:**

- Before first use, charge your LOKI Wave™ 2 for 2 hours.
- The device interface may be blocked. Hold + and - for 3 seconds.
- Press the On/O button to turn it on.
- Press the or V buttons to cycle through the 12 modes.
- Use the + or - buttons to increase or decrease the intensity.
- Press and hold the On/O button to turn it off.